

MONTAGEANLEITUNG

sun-10471ac · Audi Q2 · 2016-

DE: Montageanleitung

MT: Istruzioni per l'installazione

EN: Installation instructions

NL: Montagehandleiding

DK: Installationsvejledning til

PL: Instrukcja montażu

EE: Paigaldusjuhised

PT: Instruções de montagem

FI: Paigaldusjuhised

RO: Instrucțiuni de asamblare

FR: Instructions de montage

SE: Monteringsanvisningar

GR: Οδηγίες συναρμολόγησης

SK: Návod na montáž

IE: Treoracha tionóil

SI: Navodila za sestavljanje

IT: Istruzioni di montaggio

ES: Instrucciones de montaje

HR: Upute za sastavljanje

CZ: Návod k montáži

LV: Montāžas instrukcija

HU: Összeszerelési útmutató

LT: Surinkimo instrukcijos


BG: Инструкции за сглобяване



2x A




6x SC3-80




1x C



3x SC8-10



1x




MONTAGEANLEITUNG

sun-10471ac · Audi Q2 · 2016-

2x A




6x SC3-80



1



2



3



4



5



6



7



8

MONTAGEANLEITUNG

sun-10471ac · Audi Q2 · 2016-

